

THANK YOU for choosing i>clicker, the easiest-to-use classroom response system available. i>clicker requires **no installation** and **minimal setup** for both the hardware and software.

Hardware and Software

Please contact your sales representative for your instructor hardware. You can download the i>clicker software from www.iclicker.com. For best performance, please use the USB cable provided with the base unit.

Support

- The complete user guide is available in the i>clicker software folder.
- For additional support materials, visit support.iclicker.com.
- For specific technical questions, email us at support@iclicker.com or call us at 1 800 216 395.
- To schedule training, visit iclicker.webex.com.
- For information from your peers including best practices, case studies, discussion forums, and clicker questions, visit our user community: TalkClickers.com.
- For sales inquiries or questions, contact your local i>clicker representative.

Set Up i>clicker

- 1 Visit iclicker.com to download the AU-version software to your hard drive. You may also run the software from a USB flash drive, but your hard drive will provide the best experience possible. If you do choose to run the i>clicker software from a flash drive, connect the drive directly to a USB port on your computer—not the USB port on the base receiver.
- 2 Connect the i>clicker base receiver to your computer. The LCD on the base will light up indicating that the base has power.




IMPORTANT: Connect the base directly to your computer; do not connect through a keyboard or non-powered USB hub.

- 3 Locate and open the *iclicker 7* folder. Launch the program by double-clicking the i>clicker icon.



- 4 From the *i>clicker Home* window, click **+ Create** button and enter your course name.



Customize Your Class

Access these settings and more by clicking the **Settings** button on the *i>clicker Home* window.

1 General tab:

The screenshot shows the 'General' tab of the i>clicker Settings window. It includes fields for Course Name, Instructor Remote ID, and Welcome Message. There are also sections for Frequency Code (Subfrequency Code 1 and 2) and Regional Settings (Choose Language and Show language selection at start-up). Buttons for 'Cancel' and 'Save' are at the bottom right.

Instructor Remote: Enter your instructor remote's 8-character code here. This will activate it to control your classroom presentations and i>clicker polls.

Frequency Code: Change your base receiver's 2-letter code from the default AA if you need to prevent interference from other nearby base receivers.

2 REEF Polling tab:

The screenshot shows the 'REEF Polling' tab of the i>clicker Settings window. It features the REEF Polling logo and a description of the feature. A button labeled 'Enable REEF Polling' is prominently displayed. Below it is a link 'Learn More About REEF Polling'. 'Cancel' and 'Save' buttons are at the bottom right.

Enable REEF Polling: Use these settings to enable student to vote with REEF Polling (mobile clicker for laptops, smart phones, tablets and other mobile devices).

IMPORTANT: You need an Internet connection in order to edit REEF Polling settings.

3 Gradebook tab:

The screenshot shows the 'Gradebook' tab of the i>clicker Settings window. It includes a section for 'Learning management system (LMS)' with a dropdown menu and a 'Router Source' field. There is also a section for 'Locally-hosted registration database' with a 'Server URL' field. 'Cancel' and 'Save' buttons are at the bottom right.

Gradebook: The integrated gradebook set-up, including selecting your learning management system (LMS), appears on this tab. If your admin has preconfigured i>clicker to integrate with your LMS, you will enter your LMS credentials here instead of selecting the LMS.

4 Scoring tab:

The screenshot shows the 'Scoring' tab of the i>clicker Settings window. It contains sections for 'Participant points' and 'Performance points'. The 'Participant points' section has a 'Session participation points' field and a 'To earn participation points students must respond to' dropdown. The 'Performance points' section has 'Points for responding' and 'Points for correct response' fields, and a checkbox for 'Link the total performance points earned in a session to a maximum of'. 'Cancel' and 'Save' buttons are at the bottom right.

Participation Points: Enter points students receive for participation, which is awarded all-or-nothing for an entire session.

Performance Points: Enter the points students receive for responding and for responding with the correct answer. Performance points are awarded per question.

Start a Polling Session

- 1 From the *i>clicker Home* window, select a course then click the **Start New Session** button.
- 2 The *Session Toolbar* appears in the top-left corner of your screen. This toolbar can be repositioned anywhere on your desktop.
- 3 When you are ready to start polling, present the question to your students and have them turn on their clickers. If necessary, switch the question type using the drop-down menu control on the **Start** button.



- Use type **Multiple Choice** for **Multiple Choice**, **True/False**, **Yes/No**
 - Use type **Numeric** for **Numeric** (open-ended response)
 - Use type **Short Answer** for **Alphanumeric** (open-ended response), **Multiple Response**, **Order/Rank/Sequence**
- 4 Click the **Start** button to begin polling. Once polling is active, this button switches to become a **Stop** button.